

ASSEMBLY & INSTRUCTIONS

IMPORTANT! TO PREVENT ELECTRICAL SHOCK, TURN OFF ELECTRICITY AT CIRCUIT BREAKER OR FUSE BOX BEFORE PROCEEDING WITH INSTALLATION.

Remove all parts and parts packages from carton.

Thread two long Machine Screws and Green Ground Screw into Mounting Strap.

Fasten Mounting Strap to Outlet box (not provided) with Mounting Screw.

Mounting Screw.

Connect the wires. Splice the black, smooth, or round Fixture Wires to the Black Supply Wire and the white, ribbed, or flat-sided Fixture Wires to the White Supply Wire using wire Connectors.

CAUTION: Be certain that no bare wire strands are exposed outside of the wire connectors.

Attach the Ground wire onto the Mounting Strap with Ground Screw and tighten.

Carefully tuck all spliced wires into the Outlet box. Mount Fixture Pan to ceiling allowing Machine Screws to pass through holes in the Fixture Pan and secure with Small Ball Nuts. Install lamp (not included).

Put Glass Shade into Ring and secure with Clip.

Raise Glass Shade with Ring up to ceiling and secure in place with the Large Ball Nuts.

The installation is now complete and power may be reconnected at a main fuse box.

